# FRACINO

## SERVICES REQUIRED FOR INSTALLATION OF FRACINO CAPPUCCINO COFFEE MACHINES AND ASSOCIATED EQUIPMENT.

ALL MACHINES REQUIRE A MAINS WATER & POWER SUPPLY AS SPECIFIED BELOW. IT IS HIGHLY RECOMMENDED THAT A MAINS WASTE OUTLET IS PROVIDED BUT A BUCKET IS SUFFICIENT IF NOT AVAILABLE. ALL SERVICES MUST BE IN PLACE PRIOR TO INSTALLATION. ALL CALLS TO UNPREPARED SITES ARE FULLY CHARGEABLE.

**MAINS WATER:** 15mm COLD WATER SUPPLY WITH ¾" STANDARD WASHING MACHINE STOP COCK.

**MAINS WASTE:** 1 **½"** (MINIMUM DIAMETER) STAND PIPE FOR FLEXI HOSE.

**WATER & WASTE CONNECTIONS TO BE DIRECTLY BENEATH THE LOCATION OF THE MACHINE (WITHIN ONE METRE).**

**POWER SUPPLY:** *COFFEE MACHINES*

STANDARD POWER RATINGS

| | |
|---|---|
| 1 GROUP (2.7kw) | 13 AMP |
| 2 GROUP (4.0kw) | 20 AMP SINGLE PHASE |
| 3 GROUP (7.5kw) | 30 AMP SINGLE PHASE |
| 4 GROUP (7.5kw) | 30 AMP SINGLE OR THREE PHASE* |

ALTERNATIVE ELEMENT/POWER RATINGS
***(MUST BE SPECIFIED ON ORIGINAL ORDER IF ONE OF BELOW REQUIRED).***

| | |
|---|---|
| 2 GROUP (2.85kw) | 13 AMP |
| 2 GROUP (7.5kw) | 30 AMP SINGLE PHASE |
| 3 GROUP (9.0kw) | 45 AMP SINGLE OR THREE PHASE* |
| 4 GROUP (9.0kw) | 45 AMP SINGLE OR THREE PHASE* |

* ***MUST BE SPECIFIED ON ORDERING IF 3 PHASE REQUIRED.***

**POWER CONNECTION TO BE DIRECTLY BEHIND THE LOCATION OF THE MACHINE**

*GRINDERS*

ALL MODELS 13 AMP

**SOCKET TO BE LOCATED ON THE SAME SIDE OF THE COFFEE MACHINE THAT THE GRINDER WILL STAND. (RECOMMEND RIGHT HAND SIDE).**